




# Lightcloud Emergency Shunt On/Off

Lightcloud Controller emergency fixture wiring with LCShunt for on/off operation.



**Note:** The LCSHUNT includes a 20A rated high voltage Form C (N/O+N/C) relay and is UL924 Listed for emergency lighting control applications. The LCSHUNT can bypass a line voltage switch or dimmer, ensuring that an emergency fixture illuminates at full brightness during a utility power interruption.



Any wires not in use must be capped off or otherwise insulated.  
This product should only be installed by a qualified electrician and in compliance with local and national electrical codes.


**RAB**

**Controls**



# Lightcloud Emergency Shunt Dimming

Lightcloud Controller emergency fixture wiring with LCShunt/D10 for on/off and 0-10V dimmable operation.



**Note:** The LCSHUNT includes a 20A rated high voltage Form C (N/O+N/C) relay and a low voltage Form A (N/O) relay and is UL924 Listed for emergency lighting control applications. The LCSHUNT can simultaneously bypass both a line voltage switch and a 0-10V dimming signal, ensuring that an emergency fixture illuminates at full brightness during a utility power interruption.



Any wires not in use must be capped off or otherwise insulated.  
This product should only be installed by a qualified electrician and in compliance with local and national electrical codes.

**RAB**

**Controls**

# Welcome



Lightcloud<sup>TM</sup> Touch

LCTOUCH10

WE'RE HERE TO HELP:

**1 (844) LIGHTCLOUD**

1 (844) 544-4825

[support@lightcloud.com](mailto:support@lightcloud.com)

# Hello

Lightcloud is a wireless lighting control service. The Lightcloud Touch is a wall-mounted 10" touchscreen tablet that gives users a convenient and customizable interface for controlling a Lightcloud site.

## Product Features

AC-powered for permanent installation

Customizable zone and scene control


Direct local control for minimum latency

Easy setup from your computer or mobile device—or just call RAB


*Patent Pending*

# Contents

Lightcloud Touch



Instruction Manual



Six #6-18 x 1" Drywall Screws



# Specifications

## PART NUMBER

LCTOUCH10

## INPUT

120VAC, 0.3-0.15A, 50/60Hz

## OPERATING TEMPERATURE

0°C to 40°C

## MAXIMUM RELATIVE HUMIDITY

90%

## OVERALL DIMENSIONS

11" x 7.8" x 2.3"

## WIRELESS RANGE

Line of Sight	1000 feet
Obstructions	100 feet


Indoor Rated.

# What You Need



## **Lightcloud Gateway**

A Lightcloud installation requires at least one Lightcloud Gateway to manage your devices.



## **Lightcloud Controller**

*(Or similar Lightcloud actuation device)*

WE'RE HERE TO HELP:

**1 (844) LIGHTCLOUD**


1 (844) 544-4825

[support@lightcloud.com](mailto:support@lightcloud.com)

# Finding a Suitable Location


Lightcloud uses a wireless mesh network to connect devices such as the Dimmer to the Gateway. Unlike a WiFi router, each Lightcloud device may connect another device to the network. If there is a clear line of sight between two Lightcloud devices, they can be placed up to 1000 feet apart. If the two devices are separated by ordinary drywall construction, try to keep them within 100 feet of each other. Brick, concrete and steel construction may require additional AC-powered Lightcloud devices to go around the obstruction. See the Deployment section of your Gateway for more information.

# Wiring



# Setup & Installation

## ① Turn off power ⚠ WARNING



## ② Install the Touch


- Choose a junction box at which to install the Touch, keeping in mind the guidelines from "Finding a Suitable Location".
- Affix the bracket to the wall using the six #6-18 x 1" screws included.
- Connect hot and neutral wires to the wires on the back of the Touch as shown in the "Wiring" section.
- Hang the touch from the bracket.
- Tighten bracket screws on bottom surface of device.



# Setup & Installation (cont'd)


## ③ Labeling your device

For setup and maintenance, we provide two Lightcloud Device Tables with the Gateway: one that you can attach to your panel and one to hand off to a building manager. Attach the Device Identification stickers included with each device to a row, then write in additional information, such as Zone name, Panel/Circuit Number, and whether or not a zone uses dimming.



## ④ Enabling your device


- 4a Turn the Touch on by holding the power button on top.




# Setup & Installation (cont'd)

## ④ Enabling your device (cont'd)

- 4b Call RAB at 1 (844) LIGHTCLOUD, or email us at [support@lightcloud.com](mailto:support@lightcloud.com), to add the Touch to your Lightcloud network.



- 4c Once the Touch has joined your network, you'll see the screen below.



# Functionality

## Configure

All Lightcloud products can be commissioned and configured by:

- Logging on to [lightcloud.com](https://lightcloud.com)
- Calling RAB at 1 (844) LIGHTCLOUD
- Emailing us at [support@lightcloud.com](mailto:support@lightcloud.com)

### ① Configuring the Touch by calling or emailing RAB


**1 (844) LIGHTCLOUD**

1 (844) 544-4825

[support@lightcloud.com](mailto:support@lightcloud.com)

## ② Configuring the Touch using the web/mobile application

2a Navigate to <https://control.lightcloud.com> and log in.

A screenshot of the Lightcloud login page. At the top center is a circular icon containing a stylized '2'. Below the icon is the text 'Lightcloud'. Underneath are two input fields: 'Email Address' and 'Password'. Below the password field is a black 'Sign In' button. At the bottom left is a link that says 'Forgot password?'.

②

Lightcloud

Email Address

Password


Sign In

[Forgot password?](#)


# Functionality (cont'd)

## ② Configuring the Touch using the web/mobile application (cont'd)


2b Click the  menu icon in the top left.



2c Navigate to your Site, then click Devices.



2d Find your Touch device in the Device List on the left







# Functionality (cont'd)

## ② Configuring the Touch using the web/mobile application (cont'd)

- 2e Click the icon to add zone and/or scene controls to your Touch.




In this example, we've configured our Touch to control two zones and one scene:



2f

Within a few seconds, the tablet UI refreshes to reflect our changes.



### *FCC Information:*

*This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.*

*These limits are designed to provide reasonable protection against harmful interference in a non-residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference with radio or television reception, which can be determined by turning the equipment off and on, you are encouraged to try to correct the interference by one or more of the following measures:*

- Reorient or relocate the antenna.*
- Increase the separation between this equipment and receiver.*
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.*
- Consult the dealer or an experienced radio/TV technician for help.*

*To comply with FCC RF exposure limits for general population/uncontrolled exposure, this transmitter must be installed to provide a separation distance of at least 20cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.*

**CAUTION: Changes or modifications to this equipment not expressly approved by RAB Lighting, Inc. may void the user's authority to operate this equipment.**



Lightcloud is a commercial wireless lighting control system & service. It's powerful and flexible, yet easy to use and install. Learn more at **lightcloud.com**

**1 (844) LIGHTCLOUD**

1 (844) 544-4825

support@lightcloud.com

**RAB<sup>®</sup>**

© RAB Lighting, Inc

170 Ludlow Avenue Northvale, NJ 07647

Custom manufactured in China



Lightcloud is a commercial wireless lighting control system & service. It's powerful and flexible, yet easy to use and install. Learn more at [lightcloud.com](http://lightcloud.com)

1 (844) LIGHTCLOUD

1 (844) 544-4825

[support@lightcloud.com](mailto:support@lightcloud.com)

**RAB®**

Custom manufactured in China

© RAB Lighting, Inc

170 Ludlow Avenue Northvale, NJ 07647

# Welcome



Lightcloud™  
Sensor

LCSENSE15/D10 (Ceiling Sensor)

LCHBSENSE15/D10 (High Bay Sensor)

WE'RE HERE TO HELP:

1 (844) LIGHTCLOUD

1 (844) 544-4825

[support@lightcloud.com](mailto:support@lightcloud.com)

# Hello


Lightcloud is a wireless lighting control service. The Lightcloud Sensor is a remotely configurable passive infrared motion sensor that can switch and dim both hardwired circuits and remote circuits using Lightcloud Controllers.

## Product Features


Advanced PIR Sensing  
Secure Cloud Control & Configuration  
Retrofit-Friendly Local Control  
Scheduling & Astronomical Clock  
Temperature Monitoring  
Light Sensor  
Power Monitoring  
0-10V Dimming  
Patent Pending

# Contents


Lightcloud Ceiling Sensor  
or High Bay Sensor



Wire Nuts




Instruction Manual



## Accessories

For use with High Bay Sensor Only


Lens Cover for 180°  
Coverage (included)



Arm (optional, includes  
2 screws and 1 locknut)



Height Adjuster  
(optional, must use in  
conjunction with Arm)



# Specifications

Indoor Damp Location

PART NUMBER

LCSense15/D10 (Ceiling)

LCHBSense15/D10 (High Bay)

INPUT

120-277VAC, 50/60Hz,

<1W (Standby) - 2W (Active)

MAXIMUM SWITCHED LOAD RATINGS

Electronic Ballast: 277VAC, 3300W

Magnetic Ballast: 277VAC, 1200W / 120VAC, 800W

Tungsten: 220VAC, 3000W

Dimming: 0-10V (Class2)

OPERATING HUMIDITY

10% RH to 95% RH

Non-Condensing

OPERATING TEMPERATURE

-20°C to 40°C

OVERALL DIMENSIONS

4.91" Diameter, 1.61" Height

WIRELESS RANGE

Line-of-Sight: 1000 feet

Obstructions: 100 feet

Warranty is active as long as service plan is active.

## What You Need



Lightcloud Gateway


A Lightcloud installation requires  
at least one Lightcloud Gateway to  
manage your devices.

# Setup & Installation

## ① Find a suitable location

Use these guidelines when installing devices:


- If there is a clear line of sight between two Lightcloud devices, they can be placed up to 1000 feet apart.
- If the two devices are separated by ordinary drywall construction, try to keep them within 100 feet of each other.
- Brick, concrete and steel construction may require additional Lightcloud devices to go around the obstruction.



## ② Install your Lightcloud Sensor

INSTALL AT A JUNCTION BOX (INDOOR/OUTDOOR)

The Sensor can control other Lightcloud devices, wirelessly. If you don't need to hard-wire a switched circuit to the Sensor, no problem—just tie the white/red wire to neutral and cap off any unused wires.





# Setup & Installation (cont'd)


## ③ Installing Accessories (High Bay only)

Arm:

mount sensor to

fixture using ½" NPS

threaded nipple




Height Adjuster:

adjust height by loosening set screw, moving sensor up or down along extruded tube, then tightening set screw. Ensure sensor lens is not blocked by any part of the fixture.

## ④ Wiring

### SWITCHED NEUTRAL

The "Switched Neutral" white with red stripe wire is the neutral line for the load being switched. This enables power measurement. See the Power Measurement section under "Functionality" for more information.




**Any wires not in use must be capped off or otherwise insulated.**

This product should only be installed by a qualified electrician and in compliance with local and national electrical codes.

# Setup & Installation (cont'd)

## ⑤ Labeling your device



For setup and maintenance, we provide two Lightcloud Device Tables with the Gateway: one that you can attach to your panel and one to hand off to a building manager. Attach the Device Identification stickers included with each device to a row, then write in additional information, such as Zone name, Panel/Circuit Number, and whether or not a zone uses dimming.

## ⑥ Power up

To add new devices to your Lightcloud network, contact RAB:

WE'RE HERE TO HELP:

**1 (844) LIGHTCLOUD**  
or 1 (844) 544-4825  
[support@lightcloud.com](mailto:support@lightcloud.com)


## ⑦ Confirm device connectivity

Confirm status indicator LED (see step 8) is solid green. If it is not, make sure your device is within range of another Lightcloud AC-powered device.

# Setup & Installation (cont'd)

## ⑧ Place cover

Secure cover onto sensor by pushing up and twisting to the right (clockwise).




## ⑨ Commission & Configure Your Devices

All Lightcloud products can be commissioned and configured by:

- Logging on to [lightcloud.com](https://lightcloud.com)
- Calling RAB at 1 (844) LIGHTCLOUD
- Emailing us at [support@lightcloud.com](mailto:support@lightcloud.com)

# Functionality

## Overview



### STATUS INDICATOR:

- Solid GREEN when connected to your Lightcloud network
- Blinking RED when not connected to a Lightcloud network. The device will automatically continue trying to connect to a network that is in Setup Mode.

### POWER INDICATOR:

Illuminated when powered. Blinking when indicated from the Lightcloud application.

### SIGNAL INDICATOR:

After the Device Button has been pressed, this indicator illuminates when the device receives a message and indicates the strength of the signal.

3 - Best Signal

2 - Acceptable Signal

1 - Unacceptable Signal

Consult the "Finding a Location" section for more information.

### DEVICE BUTTON:

- Press once to highlight this device in the Lightcloud Application (pressing once also enables display of the Signal Indicators)
- Press twice to toggle circuit on and off
- Press twice and hold to set dim level
- Press and hold for 10 seconds to remove this device from a Lightcloud network

### MOTION INDICATOR:


Illuminates when motion is detected

### SENSOR:

Passive-infrared motion sensor

# Functionality (cont'd)

## Features: Passive Infrared Motion Detection



## Features

### OCCUPANCY & VACANCY SENSING:

The Lightcloud Sensor can operate in either Occupancy or Vacancy Sensor modes, selectable via the Lightcloud application. In Occupancy mode, the attached circuit will be switched on when motion is detected, and off (or dimmed) when the timeout expires. In Vacancy mode, the attached circuit will be turned off when the motion timeout expires, but will only be turned on via the Lightcloud application, Lightcloud Wall Switch, or similar. Motion detection and timeout can still be used via Lightcloud Automations to control other devices.

### CONTROLLER MODE:

In Controller Mode, the attached circuit is controllable as an independent zone in the Lightcloud application. Motion detection and timeout can still be used via Lightcloud Automations to control other devices.

### RANGE TEST MODE:

When Range Test Mode is activated via the Lightcloud application, the timeout period is shortened so that you can test different sensitivities quickly. All indicators will go off except for the Motion Indicator. When satisfied, turn off Range Test Mode to continue normal operation.

# Functionality (cont'd)

## Features

### 0-10V DIMMING:

0-10V is a common method of low-voltage control of dimmable drivers and ballasts.

Purple: 0-10V positive | Gray: 0-10V common

Note: The National Electrical Code requires that low-voltage wiring used in the same enclosure as high voltage wiring have an equal or better insulation rating. You may need to complete your low-voltage wiring in another enclosure or use a partition.

### DEVICE IDENTIFICATION:

For help with installation, there are two ways to identify this device:

- Pressing the Device Button on the actual product will produce a message in the Lightcloud application indicating which device you are working with.
- Pressing the “Indicate” button in the Lightcloud application will cause the device’s Status Indicator to blink green. This will also switch the device’s relay on and off repeatedly, allowing you to quickly identify which circuit it is.

### POWER MEASUREMENT:

The Lightcloud Sensor is capable of measuring the power usage of the attached circuit. In order to utilize this function, the neutral wire of the load must be connected to the white-red switched neutral wire. If this wire is not used, it should be tied to the regular neutral wire (i.e. all neutral wires joined).

### POWER LOSS DETECTION:

If power to the Sensor is lost, the device will detect this and alert the Lightcloud application.

### EMERGENCY DEFAULT:

If communication is lost, the Sensor may optionally fall back to a specific state, such as turning the attached circuit on. This may be configured via the Lightcloud application or by calling RAB.

### FCC Information:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This device has been tested and found to comply with the limits for Class B digital devices pursuant to Part 15 Subpart B, of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential environment. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To comply with the FCC's RF exposure limits for general population / uncontrolled exposure, this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

CAUTION: Changes or modifications to this equipment not expressly approved by RAB Lighting may void the user's authority to operate this equipment.



# Manual

# Device Specifications

## PART NUMBER

LCGATEWAY

## ELECTRICAL

The Lightcloud Gateway is designed to be hard-wired to AC power by a qualified electrician.

## INPUT

120-277 VAC, 50/60 Hz

60-45mA

## BATTERY

Li-ion battery. Contact RAB only for replacement batteries.

**CAUTION! RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO LOCAL LAWS.**

Some communities offer recycling or collection of rechargeable batteries—contact your local government for disposal practices in your area.

## DISCONNECT

An external readily accessible disconnect device, such as a circuit breaker, is required.

Custom manufactured in China

Copyright © 2016 RAB Lighting, Inc.





# Contents

5	<b>Introduction</b>
6	<b>System Overview</b>
7	<b>Lightcloud Gateway</b>
8	<b>Lightcloud Devices</b>
9	<b>Finding a Suitable Location</b>
10	Best Practices
11	Best Practices
12	Getting Started
13	<b>Installation</b>
14	Lightcloud Gateway
17	Lightcloud Devices & Table
18	<b>Setup</b>
18	Network Setup
18	Gateway Activation
18	Lightcloud Devices



# Welcome to lighting control that just works.

Lightcloud is a cloud-based wireless lighting control system that makes it easy to take charge of your lighting—from sensing to dimming, schedules to scenes, and everything in between. Control and configure your system remotely using the Lightcloud Application, or call RAB to have our experts set up your system just how you need it.

# System Overview


An individual Lightcloud installation, or Site, requires at least one Lightcloud Gateway depending on the environment and usage. Your Lightcloud devices communicate with each other and the Gateway via a wireless mesh network, which allows site layout to be flexible and robust.

The Lightcloud Gateway and Devices require a subscription to function beyond the installation period. Call RAB at **1 (844) LIGHTCLOUD** or visit [lightcloud.com](http://lightcloud.com) to set up your account. Your Lightcloud subscription gets you these state-of-the-art features:

- Online control & configuration at [control.lightcloud.com](http://control.lightcloud.com)
- Device commissioning
- Free support
- Telephone concierge
- Energy monitoring


# Lightcloud Gateway

The Gateway connects your system to our secure, private server via a cellular signal, so you don't have to worry about providing your own internet connection. With the Gateway powered and connected, your Lightcloud site is at your command with the Lightcloud Application. For maximum security, the Gateway isn't exposed to the internet at all, and for maximum reliability, the Gateway contains an Uninterruptible Power Supply (UPS) that will maintain power for up to 2 hours. When the Gateway is not powered or available, switching devices such as the Controller will fall back to a configurable emergency mode, such as turning on to full brightness.




# Lightcloud Devices

## LIGHTCLOUD DEVICES THAT CONNECT TO THE GATEWAY




### Lightcloud Controller

The Controller switches circuits up to 20A as well as provides a 0-10V dimming interface for dimmable drivers and ballasts.




### Lightcloud Ceiling Sensor

The Ceiling Sensor is an intelligent passive infrared motion sensor that can be configured for both occupancy and vacancy sensing. Switches up to 15A and provides 0-10V dimming.



### Lightcloud Daylight

The Daylight is an innovative, self-powered daylight harvesting sensor that measures available light and adjusts your lighting automatically.



### Lightcloud Dimmer

The Wall Dimmer puts advanced control at your fingertip. Configure via the Lightcloud App to switch & dim a zone or change scenes.

# Finding a Suitable Location

The Gateway should be installed in a dry or non-condensing damp environment only.

Use these guidelines when installing additional Lightcloud devices:

- If there is a clear line of sight between two devices, they can be placed up to 1000 feet apart.
- If the two devices are separated by ordinary drywall construction, try to keep them within 100 feet of each other.
- Brick, concrete and steel construction may require additional devices to go around the obstruction.

# Best Practices

Unlike an ordinary WiFi router, where all devices must be within range of the router, hardwired Lightcloud devices extend the range of the network—so as long as each device is within range of another, you'll have a strong, reliable system.

**NOTE:** *Lightcloud Daylight devices do not extend the range of a Lightcloud network.*

## PROBLEM MATERIALS



METAL




CONCRETE



BRICK

Large amounts of metal, concrete and brick are bad news for radio signals; in some cases, you'll have to go around these obstacles with additional AC-powered Lightcloud devices.







## Best Practices (Continued)

Lastly, consider sources of invisible interference.  
Avoid placing Lightcloud devices near microwaves,  
motors (especially elevator mechanical rooms)  
or any other radio amplifiers and antennas.

### PROBLEM DEVICES & SIGNALS



MICROWAVES




ELEVATOR MECHANICAL ROOMS



AMPLIFIERS & ANTENNAS


# Getting Started

## INSIDE YOUR GATEWAY



## CONTAINS

- 2x Wire Nuts
- 2x Mounting Screws
- 4x Device ID Labels
- 1x Power Cable\*



## ACTIVATION STEPS

## GATEWAY

## DEVICE TABLE

ID	Name	Status	Location
0013A200	4006244A		
0013A200	4006244A		
0013A200	4006244A		
0013A200	4006244A		


## MANUAL



*\*The Lightcloud Gateway must be mains powered for permanent installation. Power cord including for testing cellular signal strength at different locations in a facility.*

# Installation

The Lightcloud Gateway is rated 120-277VAC and contains an integral junction box for hard-wired installation by a qualified electrician.



## LED Indicators

### POWER

**Green:** Fully powered

### CELLULAR

**Off:** No or poor cellular signal. You must move the Gateway to a location with better cellular signal.

**Solid Yellow:** Adequate cellular signal. This signal strength works for most applications, but if possible, move to a location with better signal.

**Solid Green:** Good cellular signal.

### SYSTEM STATUS

**Blinking Yellow:** Initializing

**Solid Yellow:** Error: Cannot reach Lightcloud service. Check Cellular Signal Strength and call RAB for technical support.


**Blinking Green:** Ready to connect with new Lightcloud devices

**Solid Green:** Normal operation

# Installing the Lightcloud Gateway

Follow instructions and steps to successfully install your Gateway.


## 1 STEP ONE



Choose a location with good cellular signal. Check your phone's signal for reference.


**NOTE:** Locations with significant concrete and brick construction, or underground locations, are not recommended. **Do not install inside metal enclosures.**

## 2 STEP TWO




Turn off the breaker and prepare the circuit you'll use to power the Gateway. A dedicated circuit is recommended.

## 3 STEP THREE



Remove a knockout (KO) from the Gateway using a flat-blade screwdriver and hammer. Place the screwdriver blade at the edge of the KO, then tap the screwdriver with the hammer to weaken the attachment. Work your way around the edge of the KO until it breaks away.


#### 4 STEP FOUR



Mount the Gateway to the installation surface using size 10 screws appropriate for the surface material. For direct installation onto an external junction box, use the junction box's included screws.

**NOTE:** Conduit must be used to connect to side knockouts.


#### 5 STEP FIVE



Install included battery with negative (-) end facing towards junction box area. Call RAB to request replacement rechargeable batteries. Use RAB-provided batteries only.

Connect hot and neutral wires with included wire nuts.


#### 6 STEP SIX



Turn breaker back on.

# Installing Lightcloud Gateway (Continued)

## 7 STEP SEVEN




Turn on the Gateway main power switch. Replace outer cover and use included screws to secure.

When all devices are installed and powered, you're ready to call RAB to activate and verify your system, and complete your site's configuration.

**NOTE:** Use only RAB-authorized parts.


## 8 STEP EIGHT



Confirm that the cellular signal strength LED is yellow or green. If the Gateway is powered but this LED is not lit, relocate the Gateway to an area with better reception.

*You can use the included power cable to easily test the signal strength in a few locations, but remember that the Gateway must be hardwired for permanent installation.*

## 9 STEP NINE



Place extra Device ID stickers on your Lightcloud Device Table (see page 18) for future reference.

*For each device, find the number from the panel board and write it down on the Device Table.*

# Lightcloud Devices

Lightcloud devices that are mains hard-wired powered are designed to be installed on a junction box or similar enclosure, and must be installed by a qualified electrician. Refer to your device's manual for installation considerations and best practices.

**TIP:** Use extra Device ID stickers on or near your devices or circuits for easier identification.

## Lightcloud Device Table


The Device Table is essential for referencing during setup or for troubleshooting—don't forget it! Two copies are provided: one to keep near your Gateway, and one for the building owner or facility manager to file.

### IN THE BOX




### MOUNT IT

Mount device table to breaker box.



### HOW TO USE IT

Place Gateway ID sticker at the top.



**PWR/ENGY:** if a zone uses the Controller's integrated power monitoring, place a checkmark.

**DIM:** if a zone uses the Controller's 0-10V dimming wires, place a checkmark here.

# Setup

## Gateway Activation

When you power your Gateway and it shows sufficient cellular signal (solid yellow or green LED), call **1 (844) LIGHTCLOUD** or 1 (844) 544-4825 to activate it and complete the rest of your site setup.

## Network Setup

To add new devices to your Lightcloud network, call RAB at **1 (844) LIGHTCLOUD**.

## Software Setup

Lightcloud is cloud-based—no software to install or maintain, ever. Once you have a Lightcloud account, you can login to [lightcloud.com](https://lightcloud.com) at any time to configure and control your system.

## Full Service

Need to change something about your system? No need to log in—RAB can do it for you! Call **1 (844) LIGHTCLOUD** and our support specialists will get you where you want to be.



### *FCC Information:*

*This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:*

- 1. This device may not cause harmful interference, and*
- 2. This device must accept any interference received, including interference that may cause undesired operation.*

*Note: This device has been tested and found to comply with the limits for Class B digital devices pursuant to Part 15 Subpart B, of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential environment. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:*

- Reorient or relocate the receiving antenna.*
- Increase the separation between the equipment and receiver.*
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.*
- Consult the dealer or an experienced radio/TV technician for help.*

*To comply with the FCC's RF exposure limits for general population / uncontrolled exposure, this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.*

*CAUTION: Changes or modifications to this equipment not expressly approved by RAB Lighting may void the user's authority to operate this equipment.*





Lightcloud is a commercial wireless lighting control system & service. It's powerful and flexible, yet easy to use and install. Learn more at [lightcloud.com](http://lightcloud.com)

**1 (844) LIGHTCLOUD**

1 (844) 544-4825

**RAB<sup>®</sup>**

© RAB Lighting, Inc

170 Ludlow Avenue Northvale, NJ 07647  
Custom manufactured in China

# Welcome



Lightcloud<sup>™</sup>

**Dimmer**

LCDIMMERW

WE'RE HERE TO HELP:

**1 (844) LIGHTCLOUD**

or 1 (844) 544-4825

# Hello

Lightcloud is a wireless lighting control service.

The Lightcloud Dimmer is an in-wall switch that connects wirelessly to a Lightcloud Controller to provide switching, dimming and scene control.

## **Product Features**

Wireless Control & Configuration

Zone Switching & Dimming


Dim Level Indicator

Scene Selection


Nightlight

# Contents


Dimmer




Faceplate



Faceplate Bracket



Instruction Manual



2x 6-32 1/2" Screws



2x 6-32 5/16" Screws



# Specifications

## PART NUMBER

LCDIMMER/W

## INPUT

120-277VAC, 50/60Hz, 2W

## OPERATING TEMPERATURE

0°C to 40°C

## DIMENSIONS

Dimmer: 1.77"W x 2.7"H x 1.49"D

Faceplate: 2.94"W x 4.69"H x 0.06"D

Faceplate Bracket: 2.8"W x 4.55"H x 0.13"D

18AWG grounding; terminals supporting up to 12AWG wire

## WIRELESS RANGE


Line-of-Sight: 1000 feet

Obstructions: 100 feet


# What You Need




**A Lightcloud Gateway**



**A Ceiling Sensor**  
*(Or similar actuator)*



# Wiring



## CAUTION

- Use only copper wire.
- Do not operate with the faceplate removed.
- This product should only be installed by a qualified electrician and in compliance with local and national electrical codes.
- This product should only be installed in a UL-approved single gang wall-box enclosure.
- Indoor use only.

WE'RE HERE TO HELP:

**1 (844) LIGHTCLOUD**

or 1 (844) 544-4825

## Finding a suitable location


Lightcloud uses a wireless mesh network to connect devices such as the Dimmer to the Gateway. Unlike a WiFi router, each Lightcloud device may connect another device to the network. If there is a clear line of sight between two Lightcloud devices, they can be placed up to 1000 feet apart. If the two devices are separated by ordinary drywall construction, try to keep them within 100 feet of each other. Brick, concrete and steel construction may require additional AC-powered Lightcloud devices to go around the obstruction. See the Deployment section of your Gateway for more information.

## Setup & Installation

### ① Turn off power




**WARNING**




# Setup & Installation (cont'd)

## ② Install the Lightcloud Dimmer

- 2a** Screw the line (black) and neutral (white) wires into the labeled connectors on the back of the Dimmer. Connect the ground wire (green).



- 2b** Use the two 6-32 1/2" Phillips round head screws to secure the Dimmer to the junction box.




Make sure the arrow labeled "TOP" is pointing up.




# Setup & Installation (cont'd)

## ② Install the Lightcloud Dimmer (cont'd)

- 2c** Use the two 6-32 5/16" Phillips flat-head screws provided to secure the faceplate bracket to the Dimmer.




- 2d** Snap the faceplate onto the faceplate bracket.



# Setup & Installation (cont'd)

## ③ Labeling your device




For setup and maintenance, we provide two Lightcloud Device Tables with the Gateway: one that you can attach to your panel and one to hand off to a building manager. Attach the Device Identification stickers included with each device to a row, then write in additional information, such as Zone name, Panel/Circuit Number, and whether or not a zone uses dimming.

## ④ Power up

To add your Lightcloud Dimmer to your system, enable Setup Mode via the Lightcloud application or call RAB at 1 (844) 544-4825. When the Dimmer powers up, it will automatically try to join, and keep trying until it is able to join.

*If you are installing multiple devices, you may wait until they are all installed to enable Setup Mode.*

When all devices have been commissioned, remember to disable Setup Mode.



## ⑤ Confirm device connectivity

Confirm Network Status Indicator is solid green (see details below).

# Functionality

## Configuration


To pair the Dimmer with a zone, assign scenes or perform other configuration, use the Lightcloud web application or call RAB:

WE'RE HERE TO HELP:

**1 (844) LIGHTCLOUD**

or 1 (844) 544-4825

## Overview



**DEVICE BUTTON** (*press using paperclip*):

- **Single press:** Indicate in Lightcloud application
- **Hold for 10 seconds:** Force device to leave current Lightcloud network

**DIM LEVEL INDICATOR:**

- Displays current dim level (Zone mode)

**NIGHTLIGHT:**

- **White:** Lit when zone is off so you can find the dimmer

**SIGNAL STRENGTH INDICATOR:**

- Indicates strength of the connection to next Lightcloud Device

**NETWORK INDICATOR:**

- **Solid green:** Connected to a Lightcloud network
  - **Blinking red:** Not connected to a Lightcloud network
- The network and signal strength indicators are lit for 10 minutes following initial power on. To display the indicators later on, simply press the device button once.*

**TOP AND BOTTOM BUTTONS:**

Functionality depends on which mode is being used; see next page for details.

# Functionality (cont'd)

## Features

The Lightcloud Dimmer can be used in Switch Mode, Dimmer Mode or Scene Mode. To switch between these modes and access other configuration options, use the Lightcloud web application, or call RAB at 1-844-LIGHTCLOUD.

**SWITCH MODE:** In Switch Mode, the Dimmer is paired with a specific zone to provide switching.

**Top and Bottom Buttons:**

- **Single Press:** Switch zone on/off

**DIMMER MODE:** Dimmer Mode takes Switch Mode and adds dimming capabilities.

**Top Button:**

- **Single press while zone is off:** switch zone on.
- **Single press while zone is on:** dim up to max gradually, stopping at current position if bottom button is pressed.
- **Press and hold while zone is on:** dim up gradually, release to set dim level.

**Bottom Button:**

- **Single press while zone is on:** switch zone off.
- **Press and hold while zone is on:** dim down gradually, release to set dim level.

**SCENE MODE:** In Scene Mode, the top and bottom buttons activate preselected scenes. This can be configured using the Lightcloud web application or by calling RAB.

*FCC Information:*

*This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:*

- 1. This device may not cause harmful interference, and*
- 2. This device must accept any interference received, including interference that may cause undesired operation.*

*Note: This device has been tested and found to comply with the limits for Class B digital devices pursuant to Part 15 Subpart B, of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential environment. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:*

- Reorient or relocate the receiving antenna.*
- Increase the separation between the equipment and receiver.*
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.*
- Consult the dealer or an experienced radio/TV technician for help.*

*To comply with FCC RF exposure limits for general population/uncontrolled exposure, this transmitter must be installed to provide a separation distance of at least 20cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.*

**CAUTION:** *Changes or modifications to this equipment not expressly approved by RAB Lighting, Inc. may void the user's authority to operate this equipment. Custom manufactured in China.*



Lightcloud is a commercial wireless lighting control system & service. It's powerful and flexible, yet easy to use and install. Learn more at [lightcloud.com](http://lightcloud.com)

**1 (844) LIGHTCLOUD**

1 (844) 544-4825

[support@lightcloud.com](mailto:support@lightcloud.com)

**RAB®**

© RAB Lighting, Inc

170 Ludlow Avenue Northvale, NJ 07647

Custom manufactured in China

# Welcome



Lightcloud™

**Daylight**

LCDAYLIGHT

WE'RE HERE TO HELP:

**1 (844) LIGHTCLOUD**

1 (844) 544-4825

[support@lightcloud.com](mailto:support@lightcloud.com)

*FCC Information:*

*This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:*

- 1. This device may not cause harmful interference, and*
- 2. This device must accept any interference received, including interference that may cause undesired operation.*

*Note: This device has been tested and found to comply with the limits for Class B digital devices pursuant to Part 15 Subpart B, of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential environment. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined*

*by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:*

- Reorient or relocate the receiving antenna.*
- Increase the separation between the equipment and receiver.*
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.*
- Consult the dealer or an experienced radio/TV technician for help.*

*To comply with FCC RF exposure limits for general population/uncontrolled exposure, this transmitter must be installed to provide a separation distance of at least 20cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.*

**CAUTION:** *Changes or modifications to this equipment not expressly approved by RAB Lighting, Inc. may void the user's authority to operate this equipment.*

# Hello

Lightcloud is a wireless  
lighting control service.  
The Lightcloud Daylight  
is a remote, self-powered,  
open-loop light sensor  
that can switch and dim  
Lightcloud Controllers  
and other Lightcloud  
devices.

## Product Features

Wireless Sensing & Configuration

Ambient Light Sensor


Innovative Self-Powered Design

No Batteries


*Patent Pending*

# Contents

Lightcloud Daylight




Instruction Manual



Mounting Screws




Straight & Angled  
Mounting Brackets



Power Supply for Setup



USB Cable for Setup



# Specifications

## PART NUMBER

LCDAYLIGHT

## OPERATING TEMPERATURE

-10°C to 40°C

## OPERATING HUMIDITY

10% RH to 95% RH

## OVERALL DIMENSIONS

5.25" x 3.16" x 1"

## USB POWER SPECIFICATIONS

Nominal Input Voltage 100-240VAC

Nominal Input Current 6mA

Nominal Power 0.2W

Frequency 47Hz-63Hz

Warranty is active as long as service plan is active.  
Indoor Rated.

# What You Need




## Lightcloud Gateway

A Lightcloud installation requires at least one Lightcloud Gateway to manage your devices.

## Lightcloud Controller (Or similar Lightcloud actuation device)

The Daylight is designed to remotely control one or more Lightcloud devices that are capable of switching or dimming, such as the Lightcloud Controller or Ceiling Sensor.



WE'RE HERE TO HELP:

**1 (844) LIGHTCLOUD**


**1 (844) 544-4825**

**support@lightcloud.com**

# Setup & Installation


## ① Plug in the Daylight device (setup only)

To join your Daylight to a Lightcloud network, plug it in with the included Micro USB power adapter. The white Power Indicator will come on and the Device Status Indicator will blink red every 10 seconds until it is joined to your network. For setup purposes, you can plug the device in anywhere that's convenient, but please stay near the location where it will be permanently installed in order to ensure continued network connectivity. Once setup has been completed, you can unplug the device and it will operate exclusively on solar power—no batteries necessary.



## ② Contact RAB to add your Daylight

Call us at 1(844) LIGHTCLOUD or email [support@lightcloud.com](mailto:support@lightcloud.com) and we'll get your Daylight device added to your Lightcloud network immediately. When USB power is removed, it is normal for this LED to be unlit.







# Setup & Installation (cont'd)

## ③ Find a Suitable Location

- 3a** The Daylight needs sunlight to operate, and must be within range of another Lightcloud device. Direct sunlight is ideal, but indirect sunlight may be acceptable if there's enough of it.




- 3b** A skylight is a great location for the Lightcloud Daylight. Be aware of where shadows will land throughout the day and position the device where it will receive the most direct sunlight.




**NOTE:** Remember, south-facing surfaces usually receive more direct sunlight than north-facing surfaces.

# Setup & Installation (cont'd)

- 3c** The Daylight includes an angled mounting bracket that can be used to maximize the amount of sunlight landing on the device's face.



- 3d** In some cases, you may want to use an extension of some kind (not included) to mount the device from the ceiling. Just be sure it ends up in direct sunlight as much as possible.



**The Daylight must be within range of a Lightcloud device or Gateway. See “Finding a Location”**




**The Daylight will not act as a “repeater” to extend the range of your Lightcloud network. If you need to extend your network range, use a Lightcloud Controller or other AC-powered device.**


# Setup & Installation (cont'd)

## ④ Install

- 4a** Screw the straight or angled mounting bracket to the mounting surface.



- 4b** Snap the Daylight onto the mounting bracket.



## ⑤ Configure

Login at [lightcloud.com](https://lightcloud.com) and click on Devices to associate a zone at your site. The application will show the last measured light level so you can configure actions to take at different levels. Or, simply call or email us:


**1 (844) LIGHTCLOUD**

1 (844) 544-4825

[support@lightcloud.com](mailto:support@lightcloud.com)

# Functionality

## Overview



### DEVICE STATUS INDICATOR:

- **Unlit:** When not powered by USB, indicates that the device is joined to a Lightcloud network and is operating normally
- **Solid green:** When powered by USB, indicates that the device is joined to a Lightcloud network
- **Green blink:** After pressing the Device Button, indicates that a light level measurement has been transmitted
- **Single red blink every 10 seconds:** Not joined to a Lightcloud network
- **Green/Red alternating:** Resetting to factory defaults

### USB POWER INDICATOR:

- **White:** Powered by USB

### DEVICE BUTTON:

- **Press:** Indicate in Lightcloud application and measure light level
- **Hold for 10 seconds while USB powered:** Force device to leave current Lightcloud network
- **Hold for 10 seconds while connecting USB power:** Reset to factory defaults and leave current network

### DAYLIGHT HARVESTING:

Daylight Harvesting is the use of daylight to offset the use of electric lighting to light a space. If there's enough daylight in a space, the Lightcloud Daylight can make sure the lights are turned down or off, and turn them back on when the sun goes down.

The Lightcloud Daylight automatically takes light level measurements every 10 minutes. Pressing the Device Button will make an immediate measurement. Call or email RAB, or log in to [lightcloud.com](http://lightcloud.com) to configure actions to take at different light levels, such as turning off a zone when the light level exceeds 50 foot-candles.

# Welcome



Lightcloud<sup>TM</sup>  
**Controller**

LCCONTROL20/D10

WE'RE HERE TO HELP:

**1 (844) LIGHTCLOUD**

1 (844) 544-4825

[support@lightcloud.com](mailto:support@lightcloud.com)

# Hello

Lightcloud is a wireless  
lighting control service.

The Lightcloud Controller  
is a remotely controlled  
switch and 0-10V  
dimming device.

## Product Features

Wireless Control & Configuration

Switching up to 20A


0-10V Dimming

Power Monitoring

*Patent Pending*

# Contents

## Lightcloud Controller



## NPT Nut




## O-ring



## Wire Nuts



## Instruction Manual



# Specifications

## PART NUMBER

LCCONTROL20/D10

## INPUT

120-277VAC, 50/60Hz  
<2W (Standby - 4W (Active))

## MAXIMUM SWITCHED LOAD RATINGS

For Control of Magnetic, Electronic Ballast or LED  
277VAC: 20A Magnetic/Resistive  
240VAC: 5A Tungsten/Electronic, 20A FLA/  
60 LRA, 2HP  
120VAC: 15A Tungsten, 1HP

## OPERATING TEMPERATURE

-40°C to +40°C

## OVERALL DIMENSIONS

1.55" diameter, 5.75" length  
1/2" NPT Mount, Male  
16AWG pigtails

## WIRELESS RANGE

Line-of-Sight: 1000 feet  
Obstructions: 100 feet

Warranty is active as long as service plan is active  
Class 2  
IP66 Rated  
Indoor and Outdoor Rated  
Wet and Damp Location  
Plenum Rated

# What You Need



## **Lightcloud Gateway**

A Lightcloud installation requires at least one Lightcloud Gateway to manage your devices.


WE'RE HERE TO HELP:

**1 (844) LIGHTCLOUD**

or 1 (844) 544-4825  
[support@lightcloud.com](mailto:support@lightcloud.com)



# Wiring




# Setup & Installation

## ① Turn off power




**WARNING**



## 1a Find a Suitable Location

Use these guidelines when installing devices:


- If there is a clear line of sight between two Lightcloud devices, they can be placed up to 1000 feet apart.
- If the two devices are separated by ordinary drywall construction, try to keep them within 100 ft. of each other.
- Brick, concrete and steel construction may require additional Lightcloud devices to go around the obstruction.



# Setup & Installation (cont'd)

## ② Install your Lightcloud Controller

### 2a Install at a Junction Box (Indoor/Outdoor)




### 0-10V DIMMING

0-10V is a common method of low-voltage control of dimmable drivers and ballasts. **Purple:** 0-10V positive | **Gray:** 0-10V common

NOTE: The National Electrical Code requires that low-voltage wiring used in the same enclosure as high-voltage wiring have an equal or better insulation rating. You may need to complete your low-voltage wiring in another enclosure or use a partition.


## 2b At Lighting Panel or Trough



Space and code allowing, you may install Lightcloud devices directly in your breaker box or lighting panel. Alternatively, break out lighting circuits and install Lightcloud devices in a separate trough.

# Setup & Installation (cont'd)

## ③ Labeling your device




For setup and maintenance, we provide two Lightcloud Device Tables with the Gateway: one that you can attach to your panel and one to hand off to a building manager. Attach the Device Identification stickers included with each device to a row, then write in additional information, such as Zone name, Panel/Circuit Number, and whether or not a zone uses dimming.

## ④ Power up

To add new devices to your Lightcloud network, call RAB at 1 (844) LIGHTCLOUD, or email us at [support@lightcloud.com](mailto:support@lightcloud.com).

## ⑤ Confirm Device Connectivity

Confirm Status Indicator is Solid Green (see details below)



## ⑥ Commission your devices

Log on to [www.lightcloud.com](http://www.lightcloud.com) or call 1 (844) LIGHTCLOUD

# Functionality

## Configuration

All configuration of Lightcloud products may be performed using the Lightcloud web or mobile application, or by calling RAB.

WE'RE HERE TO HELP:

**1 (844) LIGHTCLOUD**


or 1 (844) 544-4825

[support@lightcloud.com](mailto:support@lightcloud.com)

## Operating Modes

**CONTROLLER** Provides switching and dimming for a single zone

**TRIGGER** Detect when an attached circuit is open or closed. For example, you could attach the Controller in Trigger mode to an existing occupancy sensor to allow your Lightcloud system to react to the sensor.



**REPEATER:** Disables zone control and power measurement, and extends the range of your network.

**POWER MEASUREMENT:** The Lightcloud Controller is capable of measuring the power usage of the attached circuit. In order to utilize this function, the neutral wire of the load must be connected to the white-red sense wire. If the Switched Neutral line cannot be used, it should be tied to the regular neutral wires (i.e. all neutral wires joined).

**POWER LOSS DETECTION:** If mains power to the Controller is lost, the device will detect this and alert the Lightcloud application.

**EMERGENCY DEFAULT:** If communication is lost, the Controller may optionally fall back to a specific state, such as turning the attached circuit on.



**Any wires not in use must be capped off  
or otherwise insulated.**



### *FCC Information:*

*This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:*

- 1. This device may not cause harmful interference, and*
- 2. This device must accept any interference received, including interference that may cause undesired operation.*

*Note: This device has been tested and found to comply with the limits for Class B digital devices pursuant to Part 15 Subpart B, of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential environment. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:*

- Reorient or relocate the receiving antenna.*
- Increase the separation between the equipment and receiver.*
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.*
- Consult the dealer or an experienced radio/TV technician for help.*

*To comply with the FCC's RF exposure limits for general population / uncontrolled exposure, this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.*

**CAUTION: Changes or modifications to this equipment not expressly approved by RAB Lighting may void the user's authority to operate this equipment.**



Lightcloud is a commercial wireless lighting control system & service. It's powerful and flexible, yet easy to use and install. Learn more at **lightcloud.com**

## **1 (844) LIGHTCLOUD**

1 (844) 544-4825

[support@lightcloud.com](mailto:support@lightcloud.com)

# **RAB<sup>®</sup>**

Custom manufactured in China

© RAB Lighting, Inc

170 Ludlow Avenue Northvale, NJ 07647