


INSTRUCTIONS

FILAMENT HID INSTALLATION


RAB®

RAB Lighting is committed to creating high-quality, affordable, well-designed and energy-efficient LED lighting and controls that make it easy for electricians to install and end users to save energy. We'd love to hear your comments. Please call the Marketing Department at 888-RAB-1000 or email: marketing@rablighting.com

ED28-36-EX39-850-F-C



ED32-54-EX39-850-F-C



IMPORTANT

READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

RAB lamps must be wired in accordance with the National Electrical Code and all applicable local codes. Proper grounding is required for safety. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

WARNING: Make certain power is OFF before installing or maintaining fixture. No user serviceable parts inside.

CAUTION: This device is not intended for use with emergency exits. Risk of electric shock. Do not use if outer lamp envelope is damaged or broken.

"WARNING - Risk of fire or electric shock. LED Retrofit Kit installation requires knowledge of luminaires electrical systems. If not qualified, do not attempt installation. Contact a qualified electrician."

"WARNING - Risk of fire or electric shock. Install this kit only in the luminaires that have the construction features and dimensions shown in the photographs and/or drawings and where the input rating of the retrofit kit does not exceed the input rating of the luminaire."

"Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation"

"WARNING - To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects."



"Installers should not disconnect existing wires from lampholder terminals to make new connections at lampholder terminals. Instead installers should cut existing lampholder leads away from the lampholder and make new electrical connections to lampholder lead wires by employing applicable connectors."

"MIN. LAMP COMPARTMENT DIMENSIONS 224.6×224.6 mm for ED32-54-EX39-850-F-C"


This product is rated 120-277V, however in the US it should only be used on branch circuits rated maximum 277V nominal

LAMP INSTALLATION

1. Remove old ballast or disconnect from existing lampholder. Remove and dispose of ballast in correct manner. Shown as Fig. 1. (North America 120-277VAC)
3. Install new LED replacement lamp. Shown as Fig. 3. Be sure that the old fitting is correctly grounded. Attach retrofit label to luminaire. (North America 120-277VAC)



2. Reconnect directly to the existing lampholder. Shown as Fig. 2. (North America 120-277VAC)



Note: These instructions do not cover all details or variations in equipment nor do they provide for every possible situation during installation, operation or maintenance.

Easy Answers

rablighting.com
Visit our website for product info

Tech Help Line
Call our experts: 888 722-1000

e-mail
Answered promptly - sales@rablighting.com

Free Lighting Layouts
Answered online or by request