INSTRUCTIONS

Fully Luminous Canless Downlight Installation



RAB Lighting is committed to creating high-quality, affordable, well-designed and energy-efficient LED lighting and controls that make it easy for electricians to install and end users to save energy. We'd love to hear your comments. Please call the Marketing Department at 888-RAB-1000 or email: marketing@rablighting.com



IMPORTANT

READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

RAB fixture must be wired in accordance with the National Electrical Code and all applicable local codes. Proper grounding is required for safety. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

TO PREVENT ELECTRICAL SHOCK, POWER SHOULD BE TURNED OFF AT THE FUSE BOX BEFORE INSTALLATION. SAFETY WARNINGS:

Read all product labels and directions.

- WARNING Risk of fire or electric shock. Install this kit only in the luminaires that have the construction features and dimensions shown in the photographs and/or drawings and where the input rating of the retrofit kit does not exceed the input rating of the luminaire.
- Installation should be performed only by a qualified electrician in accordance with the National Electrical Code and relevant local codes. Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation.
- WARNING To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


WHAT'S IN THE BOX

Fixture (1) Driver box (1) Template (1)


TOOLS NEEDED

This Frameless Edge-Lit Wafer requires very few tools for installation. A screwdriver and a pair of wirecutters will help to install.


OPTIONAL ACCESSORIFS



DLPLATE/T New construction or remodel plate for T-grid ceilings



DLPLATE/WFR3468/NB Mounting plate with nailer bar



DLPLATE/SJ New construction plate for Stud/Joist



EXTCBL-FA-6
Wafer extension cable 6ft
EXTCBL-FA-12
Wafer extension cable 12ft
EXTCBL-FA-20
Wafer extension cable 20ft


INSTRUCTIONS

Fully Luminous Canless Downlight Installation




RAB Lighting is committed to creating high-quality, affordable, well-designed and energy-efficient LED lighting and controls that make it easy for electricians to install and end users to save energy. We'd love to hear your comments. Please call the Marketing Department at 888-RAB-1000 or email: marketing@rablighting.com


OPTIONAL ACCESSORIES (cont'd)




DLPLATE/WFR4




DLPLATE/WFR6



DLPLATE/WFR3456



DLPLATE/WFR4/NB/CL for 4"




DLPLATE/WFR6/NB/CL for 6"

INSTALLATION INTRODUCTIONS

- 1. Turn power OFF from the electrical panel before installation.
- 2. Use template inside box to cut hole in ceiling. (Fig. 1)






3. Open the driver box and remove the knockout(s). (Fig.2)






4. Insert the electrical supply cable through the knockout and secure with a strain relief or cord clamp. Wire driver box (Fig.3), white-white, black - black, green - green/ground.

Fig: 3



5. Place all wiring and connections back into the box, close the cover and select desired CCT. (Fig.4)





INSTRUCTIONS

Fully Luminous Canless Downlight Installation




RAB Lighting is committed to creating high-quality, affordable, well-designed and energy-efficient LED lighting and controls that make it easy for electricians to install and end users to save energy. We'd love to hear your comments. Please call the Marketing Department at 888-RAB-1000 or email: marketing@rablighting.com

INSTALLATION INTRODUCTIONS (cont'd)

6. Place the driver box into the ceiling and connect the fixture to driver box. (*Fig.5*)





7. Lifting both retention tabs upward, push until the trim sits flush against the ceiling. (Fig.6)

Fig: 6

